



Using Wi-Fi function of M thermal

Downloading M Smart Life App



Open M Smart Life App and Login



Scan this QR code to download
MSmartLife App


Open M Smart Life App and Login

Open M Smart Life App and Login




Login

Login the App




Click on Sign Up and create a new account if you have never created an account of M Smart Life before . If you have already created an account before, login with the email and password

Click on “Add Device”




Click on Add Device to add your Heat Pump Water Heater



This page would be displayed. Click on “Ready” . You must have the password of the Wi-Fi

Selecting the Wi-Fi


Login to your home Wi-Fi




Select the Wi-Fi in your home and type in the password for this Wi-Fi

Select Commercial HPWH

Login to your home Wi-Fi




Select the Central heating Water Heater



The App will automatically find out the controller, here the controller is KJRH-120F

Agree and click OK

A screenshot of a smartphone app interface titled "Add device". At the top, there's a back arrow and the title. Below the title is an image of a white wired remote control with a digital display showing "60" and "65". Below the image are four buttons: "MENU", "ON/OFF", "OK", and "UNLOCK (LONG PRESS)". Below the buttons is a list of three numbered instructions. At the bottom, there is a status bar with a checkmark and the text "Operation completed", and a large blue "Next" button. A red rectangle highlights the "Operation completed" status and the "Next" button.

Add device



1. Click the "MENU" button on the wired controller, select "WLAN SETTING" and click the "OK" button.

2. Select "AP mode" and click the "OK" button.

3. Click the right direction button on the wired controller, then click the "OK" button to enter the AP mode. The "WiFi" icon will flash.

✓ Operation completed

Next


Check the Operation Completed and click on "Next"

Start the Wi-Fi Module of Controller

Enter the Menu Button of the controller



MENU	2/2
SERVICE INFORMATION	
OPERATION PARAMETER	
FOR SERVICEMAN	
WLAN SETTING	
SN VIEW	
OK ENTER	↕



WLAN SETTING
APP MODE
RESTORE WLAN SETTING
OK ENTER
↕




AP MODE	
Do you want to activate the WLAN network and exit?	
NO	YES
OK CONFIRM	↔

Do the following setting on the Menu page of the Wired controller


Start the Wi-Fi Module of Controller

Enter the Menu Button of the controller




This icon will flash

Connect to New Wi-Fi




Once the connection starts, the app will ask you to connect your phone with another Wi-Fi

Midea_c3_xxxx




Click here and connect your phone with the new Wi-Fi

Finishing Up



Go Back to the App , it will take some time for the app to finish up



Click on "Complete" , once the Account binding is finished

How to use the APP?

Functions of Various Buttons in App




M smart Life APP User interface

The screenshot shows the app interface for 'Central heating wat...'. It features two zones: Zone1 with a temperature of 40°C and Zone2 with a temperature of 22.0°C. Each zone has a 'Set Temp.' label and a slider. A power button is visible for Zone1. The interface includes mode settings for 'Heating' and 'Curve', and a bottom menu with icons for 'Schedule', 'Silent', 'Holiday', and 'ECO'. Callouts identify various elements: 'Terminal icon' points to the Zone1 icon; 'Zone name setting/ Electric consumption setting' points to the top right menu icon; 'On/Off control' points to the power button; 'Mode setting' points to the 'Heating' mode icon; 'Temperature curve setting' points to the 'Curve' mode icon; 'Schedule' points to the 'Schedule' icon; 'ECO mode' points to the 'ECO' icon; 'Silent mode / Super silent mode' points to the 'Silent' icon; and 'Holiday away mode/ Holiday home mode' points to the 'Holiday' icon.



Note: APP interface changes from time to time as APP is updated and may change slightly vary from those in this document

How to use the APP?


Schedule Function- Day Timer



Tap the Schedule Icon to enter the Schedule Function




There are 2 types of Schedule that is Day Timer and Weekly Timer




Tap on any Schedule to adjust the detailed rules under this Schedule

How to use the APP?


Schedule Function- Weekly Timer




Tap the Schedule Icon to enter the Schedule Function



In the Weekly Timer Section, select any Day to set the Schedule for that day







Tap on any Schedule to adjust the settings under this Schedule



Inside the Schedule you can set detailed rules

How to use the APP?

Silent Mode




Tap the Silent Icon to enter the Silent Mode

Firstly turn on the Silent Mode and choose between the Silent and Super Silent Mode . Thereafter you can select the Timer for Silent mode to turn on and turn off



Here you can set the Timer for different silent modes

How to use the APP?

Holiday Function- Holiday Away




Tap on the Holiday Icon and go to the Holiday Away Mode





Firstly tap on the Holiday Mode to activate the Holiday Away mode and then select the Start and End time

How to use the APP?

Holiday Function- Holiday Home




Tap on the Holiday Icon and go to the Holiday Away Mode





Firstly tap on the Holiday Mode to activate the Holiday Away mode and then select the Start and End time

How to use the APP?

Eco Function



Tap the Eco Function



Select the Timer On and Timer OFF for the Eco function here



Thank you